

Double-Sided VATS Key Adapter

TT4006



The TT-4006 VATS key adaptor is designed to upgrade existing VATS interrogators to read the newer double-sided VATS keys. The adaptor can be used in several different ways, depending on which interrogator it is to be used with. The instructions below are divided into sections. Please refer to the appropriate section for the interrogator that you own.



KENT MOORE & ALL-LOCK INTERROGATORS

Note: The “Modular to Modular” lead is not used with this interrogator. It is intended to be used only with the Tech-Train TT-4004 VATS Interrogator/Reader.

Plug the “Modular to VATS” lead into the modular socket at the rear of the adaptor. Then, plug the VATS plug from the “Modular to VATS” lead into the matching lead from your interrogator. Turn the interrogator on, the display in your interrogator should now read “E”. (If the display does not read “E”, check to make sure that there is not a key in either the adaptor or the key reader that is built into your interrogator.)

Place the key that you wish to read into the slot in the adaptor. The resistor pellet number will appear in the LCD window of your interrogator as usual.

Caution: Make sure that no key is inserted into the lock that is built into your interrogator. This will lead to a false reading of the resistor pellet number.

STRATTEC AND UNIGARD

Note: The “Modular to Modular” lead is not used with this interrogator. It is intended to be used only with the Tech-Train TT-4004 VATS Interrogator/Reader

The TT-4006 VATS key adaptor can be used with these interrogators only in conjunction with another adaptor. There are two different ways to adapt the double-sided VATS key adaptor to your interrogator.

1. Use the Tech-Train TT-4002 VATS ByPass Adaptor.
2. Use an All-Lock or Strattec plastic VATS key.

Method #1 (using the Tech-Train TT-4002)

Plug the “Modular to VATS” lead into the modular socket in the double-sided VATS key adaptor. Plug the VATS end of the “Modular to VATS” lead into the matching plug on the TT-4002 VATS ByPass Adaptor. Place a mechanical “work” key into the ByPass adaptor, and then plug the

work key into the key reader socket in the interrogator. Place the key that you wish to read into the slot in the key adaptor. You can now read the resistor pellet number from your interrogator as usual.

Method #2 (using a plastic VATS key)

Plug the “Modular to VATS” lead into the modular socket in the double-sided VATS key adaptor. Plug the VATS end of the “Modular to VATS” lead onto the connector that is built into the plastic VATS key. Plug the plastic VATS key into the reader socket in the interrogator. Place the key that you wish to read into the slot in the key adaptor. You can now read the resistor pellet number from your interrogator as usual.

TECH-TRAIN TT-4004 VATS INTERROGATOR READER

The TT-4006 VATS key adaptor can be used in two different ways with this interrogator.

Method #1 (using the “Modular to Modular” lead)

Plug either end of the “Modular to Modular” lead into the modular socket in the double-sided VATS key adaptor. Plug the other end of the “Modular to Modular” lead into the interrogator in place of the coil-cord. Place the key that you wish to read into the slot in the key adaptor, and read the key as usual.

Method #2 (using the “Modular to VATS” lead)

Plug the “Modular to VATS” lead into the modular socket at the rear of the adaptor. Then, plug the VATS plug from the “Modular to VATS” lead into the matching lead from your interrogator. Place the key that you wish to read into the slot in the key adaptor, and read the key as usual.