
Jiffy-Jak Light

TT1200



A. Lens Cap (Part# TT1200S02)

Must be pushed down as far as it will go over the ridge of the knurled base.




B. High Intensity LED Housing

Screws onto The knurled base.



C. Knurled Base

For easy gripping, attaches directly to the threaded end of the rod.



D. Battery 6V Alkaline (Part# TT1200S03)

Must insert the with positive (+) down.

Screw light onto the threaded end of rod. To turn light on, turn the High Intensity LED Housing clockwise until on. To turn light off, turn the High Intensity LED Housing counter clockwise making sure it's backed off enough so the light will not vibrate back on.



Fax 859.885.1731

800.654.0637

LOCKMASTERS[®]
INCORPORATED

2101 John C. Watts Dr., Nicholasville, KY 40356

salesinfo@lockmasters.com www.lockmasters.com